










































WASHER/DRYER

The washer-dryer should work much like your one at home, but we appreciate that each machine is slightly different, so we have included some information for you below to help you if you need it.

Meaning of the symbols and what they do:

										
Prewash	Fast	Fast +	Extra Rinse	Extra Water	Anti Crease	Pet Hair Removal	Steam	Night Mode	Soaking	Rinse Hold
										
Steeping	AutoDose	Liquid Detergent Selection	Softener Selection	Rinse	Spin+Drain	Drain	Temperature	Spin	No Spin	Tap Water (Cold)
										
No Water	Time Delay	Door Lock	Child Lock	On/Off	Start/Pause	Soil Level	Add Garment	Downloaded Program	Wash	Ok (End)
										
Cancel	AntiCrease +	Drying	Extra Dry	Cupboard Dry	Iron Dry	Timed Drying	Clean + Wear			

Laundry type	Weight (g)
Bathrobe	1200
Fabric napkin	100
Bed sheet	700
Bed sheet	500
Pillowcase	200
Tablecloth	250
Towel	200
Hand towel	100
Women's night gown	200
Underclothing	100
Men's overalls	600
Men's shirt	200
Men's pyjamas	500
Blouses	100